

display better with
BEST MANNEQUINS

MANUAL

Thank you for choosing a quality product by Best Mannequins. In order to enjoy the rack for a long time, please pay attention to our care and handling recommendations.

PARTS

1. base
2. long upright (to fixate in the base)
3. short upright (to fixate in the leg)
4. torso

Optional components :


5. arms & hands
6. head
7. touch-up kit

HANDLING & CARE GUIDELINES

- We recommend to (dis)assemble the bust on a soft surface to avoid any damage.
- Please always remove any jewellery before handling a display bust to avoid scratches. We recommend to use the provided gloves to avoid marking or soiling the torso.
- Embedded in the box, you will find a touch up kit to repair minor paint damages. Please brush softly the damaged area with sandpaper. Make sure the paint is well shaken before use. We recommend using a long stick to stir the paint at the bottom. Let the paint dry in a warm area.
- While dressing, one often inserts the arms through the neck opening of the garment. Please ensure that the hook is opposite from the chest and rotate the arm only when the position of the hook is in front of the insert in the body. This way you avoid damaging the paint on the mannequin with the hook.
- In order to clean the bust, please use a slightly moistened cloth with detergent that has been diluted with water. Minor soiling can be removed with an eraser. With major soiling through zippers, jewellery, etc., please use the enclosed cleaning sponge which you can also moisten with water.

Best Mannequins bvba

Splenterbeekstraat 2 | B-8710 Wielsbeke | Tel. 0032 56 66 64 00 | info@bestmannequins.be



display better with
BEST MANNEQUINS

ASSEMBLING INSTRUCTIONS

STEP 1 :


Please take off all jewellery.

STEP 2 :

Use a cutter knife / scissors to open the package. Don't cut too deep to avoid damage on any of the components. Take all the parts out of the box one by one and place them on a soft surface.

STEP 3 :

Install the base on the floor. Screw the long upright clockwise into the base plate (3A). Then take the shorter upright to place into the tube of the long upright. By turning the screw wings, you can place it at height and adjust if needed (3B). Please see below the different bases we provide, but all work approximately the same.



We stay at your disposal for any further assistance you might require.